Title: (avab)
Creator: Adobe Illustrator(TM) for Wi
CreationDate: (94-03-06) (18.56)

How to record a device

1. Record a preset, group or effect as usual.

2. Record the values of the parameters of the device in the preset with **Record positions, Local menu** (right mouse button or *Shift F10*) or the **Record positions** key on your console.



3. Here you will have several alternatives.
Ok mask gives you the chance to mask away some of the parameters that you may not want to have recorded.
Change position gives you the chance to record the values of your parameters of the device in a different ~~preset~~sequence step.
Cancel cancels the recording.
OK records without modifications.

Title: (avab)
Creator: Adobe Illustrator(TM) for Wi
CreationDate: (94-03-06) (18.56)



4. When **Recording positions** the values of the parameters of the device will be linked to the sequence in an **Attribute link**. This link will normally be executed when the link enters **X2** in a crossfade.
If the **Go-on-go** tag is set the link will be executed when pressing **Go**, which in most cases is preferable.
Set the **Go-on-go** tag in the **Attribute link** below **G** in the sequence menu bar.